

# spoilerlights.com

## Installation Instructions

**Please Note:** Please read thoroughly and completely before attempting removal or installation. These instructions are general in nature. The installation steps and methods involved may differ between various make and model vehicles and spoiler light types. We always recommend our customers have their spoiler lights removed and installed by a certified automotive specialist. Customers wishing to remove and install their own spoiler light proceed at their own risk. Please email [support@spoilerlights.com](mailto:support@spoilerlights.com) with any questions or concerns. We are here to help you...

### Step 1: Determine your Spoiler Light Mounting Method

1. Observe if your light is mounted with screws or with 3M tape. If you do not see any screws holding your spoiler light into the spoiler, your light is most likely mounted with 3M tape.

### Step 2: Remove your old Spoiler Light

**Screw Mounted:** Unscrew and remove screws from spoiler light housing. If you have trouble accessing the screws, try using an L-SHAPED screw driver to access the screws. **Please Note:** In some cases the entire spoiler must be removed to access the spoiler light mounting screws.

**3M Tape Mounted:** Find some fishing wire. Cut a 3' section of fishing wire. Make a loop with the fishing wire. Slip the loop around the back edge of the spoiler light. Grasp each end of the fishing wire gently pulling it back and forth in a sawing motion. Continue pulling the line back and forth across the entire back side of the spoiler light until you have completed sawed off all the 3M tape backing. The light should be easily removable once the backing has been sawed through completely.

**Screw Mounted with 3M Tape:** In some cases, some spoiler lights are mounted with both screws and 3M Tape. If you find that once you have removed the screws but are still unable to remove the light, try following the instructions above for removing possible 3M tape backing. Once you have removed the screws and/or 3M tape, gently pull the spoiler light out of the spoiler.

1. Try gently pulling the wiring to access as much wire as possible. Do not pull hard or tug on the light or wiring.
2. Look for a wire connector. If you find one, disconnect the spoiler light from the connector and remove. Use some masking tape or painters tape to secure the female wire connector leading into your spoiler to the outside of your vehicle. Otherwise the wiring can fall back down into the spoiler and you will have to fish it out. Not fun.
3. If you do not find a wire connector, we recommend you splice the wiring of your old light into the wiring of your new light to simplify the installation process. To do this you will need to cut the wiring of your old spoiler light to remove the light. Make sure to allow enough wiring coming out of the spoiler to reconnect to your new spoiler light.

### Step 3: Connecting your New Spoiler Light

**Wire Connector Installation:** If you have a wire connector on your old spoiler light, we recommend you cut off the old connector and connect it to the wiring of your new spoiler light to simplify the installation process. To do this, cut the old connector off with as much wiring to spare as possible. Then splice the wires of the connector together with the wiring of your new spoiler light. Connect the wires by twisting them together. Use the screw wire connectors (provided) to secure the wires together. To connect your new spoiler light, plug the male and female connectors together.

**Wire to Wire Installation:** If you do not have a wire connector, splice the wiring leading into your spoiler to the wiring of your new spoiler light. Connect the wires by twisting them together. Secure the wires together by using the screw wire connectors (provided). Make sure to connect the red wire (positive) to the power wire and the black wire (negative) to the ground wire. In some vehicles the power wire may be red, green, etc. Use a voltage meter to determine the power wire.

### Step 4: Mounting your New Spoiler Light

**Screw Mounted:** Install the spoiler light by pushing it up into the spoiler installation area and screwing the light into the spoiler.

**3M Tape Mounted:** Make sure to clean the spoiler light installation area very thoroughly with car wash soap and water. If the old tape is very difficult to remove, you may need to use an adhesive remover such as "Goo Gone". Once the surface is cleaned thoroughly and dried, cut & apply 3M Tape (Not Included) to the spoiler light. Once you are ready to install the light, remove the adhesive backing on the tape and push the light up into the spoiler installation area. Push firmly to mount.